

# QUICK REFERENCE GUIDE FOR THE NAPCO 1632

For Service – Call 603-645-5969; 1-800-570-6478 or after hours - 1-866-835-3579

## **To Arm:**

Wait for solid **green** light on keypad and system ready. Enter your code followed by the **ON/OFF** key.

## **To Disarm:**

Enter your code followed by the **ON/OFF** key.

Note: If your code does not work the first time or if you enter the wrong code, press the **RESET** key, then re-enter your code.

## **To Disarm after Alarm:**

Enter your code followed by the **ON/OFF** key to silence the siren and disarm the system. Then press the **RESET** key to erase the alarm history display.

## **To Bypass an Individual Zone when Arming:**

Press the **BYPASS** key and then the zone # you want to bypass (2 digits, i.e. Zone 2 is 02, zone 11 is 11) then enter your code followed by the **ON/OFF** key. The zones will go back to normal when you disarm the system.

## **To Activate Chime**

Chime mode will sound a tone at the keypad when the programmed zone is faulted while disarmed. Enter the Function Menu by pressing the **FUNCTION** key (you may have to enter your user code before pressing the **FUNCTION** key). Skip functions until “Activate Chime” is displayed (press **NO** (the **INSTANT** key) until the “Activate Chime” function is displayed. When the “Activate Chime” function is displayed - press **YES** (the **INTERIOR** key). To return to normal keypad operation, press the **RESET** key. NOTE: The chime mode is disabled while armed.

## **To Bypass all Interior Zones when Arming:**

Press the **INTERIOR** key, and then enter your code and the **ON/OFF** key.

## **To Arm with Entry Delay Removed from Entry Doors:**

Press **INSTANT** key, and then enter your code followed by the **ON/OFF** key.

This allows you to walk around inside, but if any door/window is open, the alarm will immediately sound.

## **To Arm/Disarm multiple areas from one keypad:**

If you have more than one area, and have the “Manager’s Mode” programmed, you can arm any area from one keypad by pressing the numerical key representing the area number, press the [\*] button, then **ON/OFF**. In effect you will now be in that area. Enter your code, then press **ON/OFF** to arm/disarm that area (code must be valid in that area). If no buttons on the keypad are pressed, the keypad will automatically revert to the programmed area after 20 minutes.

## **Panic:**

To sound siren and have police dispatched immediately, press **P** and **\*** at the same time. To reset after sending a panic, enter your code followed by the **ON/OFF** key, enter your code again followed by the **ON/OFF** key.

## **Ambush:**

If forced to disarm the system by an assailant, enter 66 then your code followed by the **ON/OFF** key. This will disarm the system, but will send a silent alarm to the central station monitoring facility and the police will be dispatched immediately.

**Note:** For panic and ambush codes, the central station monitoring will **not** call the premise before dispatching the police. If you need to cancel either of these alarms you must call the central station with your account number and password immediately.

### **Trouble Display on keypad:**

Press reset to clear trouble. If this does not work, enter your code and press the function key until the reset menu comes up. Press the **ON/OFF** key. When "reset system trouble" appears, press **ON/OFF** again, and then press the **RESET** key until screen is normal.

## **System Trouble Codes on 1632 Keypad**

### **AC POWER FAIL/E01-00 SERVICE**

Power Failure - Is there a general power outage? If not:  
Check power transformer (black square box plugged into outlet near panel)  
Check for blown fuse or circuit breaker

### **LOW BATTERY/E02-00 SERVICE**

Battery below 11 volts – Usually due to AC power failure or Alarm  
Will automatically recharge after AC power restore  
If not recharged within 24 hours, it needs to be replaced

### **COMM FAIL/E03-00 SERVICE**

Unsuccessful communication to central station – Is phone line working?  
If not: Notify your phone carrier of the problem  
If so: Call the monitoring company  
Give them your account number and password  
Ask them to put your system on test  
Trip your panic alarm (see directions above)  
If this does not clear the trouble, call for service

### **WIRELESS LOWBATT/E05-NN SERVICE**

Wireless transmitter low battery (NN = receiver number)  
Call the monitoring company  
Give them your account number and password  
Ask them to put your system on test  
Remove the transmitter cover and replace battery

### **SYSTEM TROUBLE/E18-NN SERVICE**

Key fob low battery (NN = key fob transmitter number)  
Call the monitoring company  
Give them your account number and password  
Ask them to put your system on test  
Remove the key fob cover and replace battery

### **SYSTEM TROUBLE/E41-NN SERVICE**

Trouble condition on a Fire Zone  
Press the **RESET** button to silence the sounder.  
Correct the trouble, and then press the **RESET** button again.

*ANY OTHER MESSAGES: CALL FOR SERVICE*